

Bluetooth Remote Controller

Operation Manual Android IOS (See E: Below)

A : Music Mode, Video Mode

- 1 : @+A is for Music Mode. The volume is controlled with the joystick in standard mode. A for pause or play; C/D for volume.
- 2 : Some brands of mobile phones support video playing in music mode, A for play, pause and touch & hold for fast forward.

B : Game Mode (Landscape)

- 1 : @+B is for landscape gamepad game mode. The direction is controlled by the joystick, D for shooting, A for taking off. It depends on keyboardset of different brands of mobile phone.

C : VR Mode Self-timer Mode, Video Mode


- 1 : @+C switches to VR Mode. When playing a game, the direction is controlled by joystick, the front side key for shooting and taking off.
- 2 : @+C switches to Self-timer Mode. Some brands of mobile phone do not support self-timer. Mouse mode self-timer is advised to be switched by @+D.
- 3 : @+C switches to Video Mode the joystick controls fast-forward-fast-backward. Some brands of mobile phone do not support volume control.

D : Mouse Mode, Self-timer Mode

- 1 : @+D switches to Mouse Mode the Joystick controls mouse, C/D for volume and A/B for confirm and quit.
- 2 : Some mobile phone brands do not support self-timer mode, use mouse mode instead.

E : Apple IOS System

Switch the side key to IOS direction to initiate mobile connection due to the closed IOS system. C/D for the volume up and down, when using the camera, C/D also for self-timer. The A key and the Enter key for mute. The B key for return to Home and press this key twice to switch pages.



Technical Parameters

Product model: VR-Park
Size: 4.6*1.3*1.6IN
Wireless Protocol: Bluetooth 3.0 compliant
Support System: Android/IOS/PC
Support Game: Android/PC (GAMEPAD)
NES/GB/SMDSX/GBC/N64/MAME; AndroidAPK
Game Apple/IOS: Icade Game
CPU: ARM968E-S Coer
Battery: Two 1.5V AAA Batteries
Working Current: 0.5-8Ma Standby Current: 0.5-1mA
Shutdown Current: 0
Continuous Game Time: about 40-120 hours

Connection Instructions :

1. Press the power button on the Bluetooth remote.
2. Turn on Bluetooth in your smartphone settings.
3. Search for devices, choose VR-Park from available devices, connection is successful when the device indicator light stops flashing and automatically turns off to confirm connection.
4. Open compatible Apps to use your Bluetooth remote. Press + hold @ + A, B, C or D to choose the desired mode.

Troubleshooting :

1. If remote control seems to be less responsive, replace with new batteries.
2. If connection is lost, reopen the Bluetooth settings in your smartphone to reconnect.
3. In areas where there is a lot of wifi activity you may experience interference.
4. For some Android phones the A, B, C, D preset configuration might vary in functionally. Cycle through each preset configuration until desired result is reached.